




DGLP/F & DGLI/F

PROXIMITY READER

W I R I N G D I A G R A M



Warning
Do not use a switching power supply because of the interference radiation that may disturb the reading of the badges

Raccordement du lecteur auxiliaire

Terminal	
12 -----	Input Voltage 12VAC/DC
V -----	Input Voltage 12VAC/DC
1 -----	Data
4 -----	Common
5 -----	Red LED
3 -----	Green LED

For a correct installation, use the mounting supplied with the reader.
Drill a 5 MM holes and a 35 MM depth minimum.